



Radioddity **GD-77**

Digital LCD Screen



Icon	Description
	Signal Bar
H L	Output Power High(H) or Low(L)
	: Digital Mode : Analog Mode
	: Speaker On : Unread Message
	+ Indicates the transmit frequency is the receive frequency plus a frequency offset; - Indicates the transmit frequency is the receive frequency minus one frequency offset; Off net
	VOX
	Digital Mode on time slot 1 Digital Mode on time slot 2
	Monitor On
	Channel mode scan on : Normal scan; : Priority scan channel 1 : Priority scan channel 2 under 2 channels; : Keyboard lock
	Battery Bar, when display means out of battery
	Under Digital Mode, press the A / B key to switch the main channel up and down, when the double wait mode is on, work in the digital sub-channel
	Under Analog Mode, press the A / B key to switch the main channel up and down, when the double wait mode is on, work in the analog sub-channel
11	Channel Mode (1~16)
	Transmit
	Receive